

Small Antenna

Minisat Interim Public Switched Telephone Service

Installation Procedure for Electromagnetic Energy Safety Compliance

November 2003



EME Safety

The Telstra Minisat Interim Public Switched Telephone Service uses a low powered radio transmitter connected to a directional antenna. The antenna focuses the radio signal into a beam aimed at the satellite.

To comply with the Australian Radiation Protection and Nuclear Safety Agency (ARPANSA) EME safety standard, access is to be restricted to ensure the area 75cm directly in front of the antenna is not accessible.

Installation Practice

- Identify the launch angle and *EME Clearance Zone*
- Mount the antenna so the *EME Clearance Zone* is not normally accessible
- For roof mounted installations, where access to any *EME Clearance Zone* detailed below is possible – ensure that the RF sign is installed to provide safety instructions for this area
- Install the RF sign on back & front of the antenna – ensure that the sign is visible in any area immediately in front of the antenna.
- Ensure antenna cable is connected before switching on the transmitter
- Do not stand in front of the antenna without switching off the transmitter
- Provide customer with EME Information Flyer



EME Clearance Zone – 75cm directly in front of the antenna